


427 Part No. 8637
 428 Part No. 8636


1987 Body Assembly Models ZTR 427/ZTR 428

1987 Wiring Assembly Model ZTR 427




BODY WIRING LOOM - 4361
REAR WIRING LOOM - 4362
WIRING KIT - 8640
(SEE ASSEMBLY BREAKDOWN)

1987 Engine Assembly Models ZTR 427/ZTR 428



427 ONLY



428 ONLY