

308 Part No. 2575  
 311 Part No. 2575


# 1987 Transaxle Assembly Models ZTR 308/ZTR 311






# 1987 Body Assembly Models ZTR 308/ZTR 311

308 Part.No. 8641  
311 Part.No. 8642





BODY WIRING LOOM - 4357  
 REAR WIRING LOOM - 4358  
 WIRING KIT (308-311)- 8638  
 (SEE ASSEMBLY BREAKDOWN)

## 1987 Wiring Assembly Models ZTR 308/ZTR 311